TOP WING
6mm DEPRON

Do not cut foam
out. Just
Mark the foam for
the position of
collar.

