TOP WING
6mm DEPRON

Do not cut foam out. Just Mark the foam for the position of collar.

