Battery Bay hatch 6mm DEPRON

For hatches I use a tongue at one end and magnets at the other. A simple ply tab can be inserted as a grab handle.

Receiver Bay hatch 6mm DEPRON

Rear fuselage inserts. 2 Off. 6mm DEPRON. One for top and one for bottom. Clearance for rudder post made after decks installed.

